



## Installing your OBDII GPS Tracker

1. **Locate the OBDII port in your vehicle.**

Federal regulations mandate it to be within two feet of the steering wheel.

If you can't find it, seek help from OneStepGPS.com's online chat or consult your vehicle's owner manual.

2. **Plug the device into the OBDII port with the vehicle turned OFF.**

Make sure your vehicle is in an open area where the device can easily connect to GPS satellites without any obstructions. The device should start flashing and connect to the platform within ten minutes.



3. **Start tracking.**

Please use the welcome email to set up your login credentials.

You can login to view your GPS tracking online at [track.onestepgps.com](http://track.onestepgps.com).

You can also download our mobile app by searching **One Step GPS** on Google Play or the App Store.

4. **Troubleshooting Tips:**

- If the tracker does not update, take a short drive to improve location accuracy.
- If the device does not light up, first, make sure it's fully plugged into the port. If it still doesn't light up, consider trying it in a different vehicle's OBD port to check for any potential blown fuses.

### Hiding your OBD II GPS Tracker

Using a Y-Cable offers multiple advantages: it discreetly hides the tracker, keeps it securely in place to prevent accidental dislodging, and leaves the OBD port available for other uses.

Watch our demonstration video online: [Onestepgps.com/hide-gps-tracker](http://Onestepgps.com/hide-gps-tracker)

**Note:** In most GM, Mazda, Nissan, Toyota, Scion, Honda & Ford Transit models, you can easily remove the plug from its bracket by popping it out. Most Ford & Chevrolet Trucks and Vans will require the OBDII plug to be unscrewed for the y-cable installation.

Please contact One Step GPS Support if you have any questions or need troubleshooting help.